

# Product Information



**DURABOND®**



## Webcrete® Ultra Finish Premium, Fast-Setting, Latex-Fortified, Portland Cement-Based Patch

### Product Description:

Durabond® Webcrete® Ultra Finish is a fast-setting, latex-fortified, Portland cement-based patch for interior use. This product may be used to skim coat or featheredge up to 1" deep in one application. Floor covering can be installed typically in as little as 15-20 minutes over concrete, wood, ceramic and quarry tile without the requirement of priming or the use of a liquid additive. When mixed with DURABOND D-L16™ High Strength Additive instead of water, Ultra Finish can be used as an embossing leveler.

This product contains Bostik's Blockade™ Antimicrobial Protection, which inhibits the growth of bacteria, mold, or mildew on the surface of the dried cement; the dried cement resists stains caused by mold.

### Product Benefits:

- Excellent for skim coating, patching or leveling
- Feather edge up to 1" deep
- Bonds directly to Durabond D-250™ Moisture Vapor Barrier Coating without the requirement of a primer.
- May be used over properly prepared cutback and other non-water soluble adhesives over concrete.
- May be used as an embossing leveler with Durabond D-L16 High Strength Additive.
- Blockade™ Antimicrobial Protection.

### Performance Characteristics:

- Latex-fortified, Portland cement matrix
- Creamy, smooth, lump-free consistency

### Surface Preparation:

Surfaces must be structurally sound, clean and free of dust, dirt, paint, soap film, adhesive residue, grease, curing compounds and other foreign material that could inhibit bonding. Material and surface should be above 50°F.

### Mixing Instructions:

Mix 20 lbs. of Webcrete Ultra Finish to 5 quarts of clean, cool, potable water. **DO NOT OVER WATER.** Do not mix more

### PHYSICAL & CHEMICAL PROPERTIES

Pot Life:	15-20 minutes at 72°F
Mix Ratio:	5 quarts water per one 20 lb bag; 2 parts powder to 1 part water for smaller quantities.
Drying time required before floor covering installation	15-20 minutes (Depending on temperature, relative humidity and patch depth).

material than can be used in 15–20 minutes. Webcrete Ultra Finish can be re-mixed to extend its pot life, however, do not re-temper by adding more liquid. The pot life of the material is affected by jobsite conditions, the powder/liquid mix ratio and temperature of the jobsite and materials. Cold materials, substrate and mixing water will extend pot life.

### Coverage:

- 200-300 sq.ft./20 lb. bag (skimming over concrete)
- 400-500 sq.ft./20 lb. bag (skimming over plywood)
- 66.6 sq.ft./20 lb. bag (1/8")

### Application:

With the flat side of a trowel held at a 45° angle, work Webcrete Ultra Finish into the surface filling all cracks and depressions in the substrate. "Key in" but do not over trowel.

**Application over plywood:** Please refer to the proper flooring industry and APA standards for plywood subfloor installation and preparation. Clean and rough-sand the plywood. Due to the limitations of plywood as a substrate, it is not intended for use in exterior, wet interior, or applications subject to heavy/commercial traffic.

**Application over existing cutback adhesive residue:** Cutback adhesive must be dry. Thoroughly scrape the cutback adhesive residue from the floor to remove any loose pieces of material prior to installing Webcrete Ultra Finish.



Boston Street • Middleton, MA 01949 • Customer Service 888/592-8558

• Technical Service 800/523-6530

www.bostik-us.com

**Application over existing ceramic tile:** Ensure that the ceramic tile is clean and well bonded to the substrate. Mechanical abrasion with a Carborundum disk is required, followed by a clean water wash. The installation must be thoroughly rinsed and dry prior to applying the Webcrete Ultra Finish.

**Application as an emboss leveler or installation over existing VCT/Vinyl:** Webcrete Ultra Finish must be mixed with DURABOND D-L16 High Strength Additive when used as an emboss fill/leveler. Vinyl/VCT must be clean and well bonded to the substrate. Remove any loose pieces of vinyl/VCT flooring. Roughen new or smooth surfaces, or flooring with urethane wear layers. **Warning: DO NOT SAND ASBESTOS FLOORS!** The installation must be thoroughly rinsed and dried. Use the flat side of a trowel held at a 45° angle to spread a thin layer of Webcrete Ultra Finish over the embossed floor covering. An embossing leveler need only be thick enough to fill in the depressions of the floor covering. Make sure coverage is smooth and uniform; avoid over-troweling. A second application may be required on deeply embossed floors. Do not apply over cushion back or perimeter bonded sheet vinyl.

### **Limitations:**

- For areas larger than 4 sq. ft. with a consistent 1" depression, the use of a DURABOND 83P Self-Leveling Underlayment is recommended.
- This product is not designed as a wear surface; an appropriate floor covering must be installed before it is open to normal traffic.
- Cutback adhesive must be fully removed prior to installing solid wood flooring.
- Do not apply directly over gypsum-based substrates or compounds.
- The use of solvent-based adhesives over Webcrete Ultra Finish is not recommended; please refer to the applicable Durabond solvent-free adhesive.

### **Clean Up, Storage and Shelf Life:**

Wash tools immediately with water. Close container tightly and store unused powder in a cool, dry place. Product has a 6 month shelf life.

### **Packaging:**

Webcrete Ultra Finish is available in 20 lb. bags.



### **PLANT LOCATIONS**

TEMECULA, CA 92590  
TWINSBURG, OH 44087

CONYERS, GA 30207  
PAULSBORO, NJ 08066

[www.bostik-us.com](http://www.bostik-us.com)

October 2007; Supersedes all previously published literature.

### **LIMITED WARRANTY**

Bostik, Inc. warrants that the product conforms with Bostik's written specifications and is free from manufacturing defects. A PURCHASER'S SOLE REMEDY FOR NONCOMPLIANCE WITH THIS WARRANTY SHALL BE THE REPLACEMENT OF THE PRODUCT OR REFUND OF THE PURCHASE PRICE. Purchasers may address their warranty claims to Bostik, Inc., 211 Boston St., Middleton, MA 01949, Attn: Customer Service or call Bostik at 1-800-726-7845. TO THE MAXIMUM EXTENT ALLOWED BY LAW, BOSTIK DISCLAIMS ALL OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND LIABILITY FOR DIRECT, INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



Boston Street • Middleton, MA 01949 • Customer Service 888/592-8558

• Technical Service 800/523-6530

[www.bostik-us.com](http://www.bostik-us.com)